


ИНСТРУКЦИЯ ПО УСТАНОВКЕ




LS-4

ИЗОБРАЖЕНИЕ ИНСТРУМЕНТА



Список аксессуаров

 x2	 x1	 x1	 x1
 x1	 x12	 4x30 x8	 4x16 x4
 5x45 x1	 4x10 x1	 x1	 x8
 x1			




Артикул	Габариты, мм	A(mm)
062028	900x1950	885-915
062029	1000x1950	985-1015
062030	1200x1950	1185-1215

1.  x1  x1


2.  x1  x1  4x10 x1  x1

3.  x1  x2


L




 5x45 x1





R






 5x45 x1





4.  x1

5.  x8

6.  4x30 x8  x8



7.  x4  4x16 x4  x1

8.  x1

