

G8040









SECURITY CONSIDERATIONS

- 1.The installation and debugging must be operated by the qualified electrician or specialist appointed by our agents.
- 2.The equipment of connecting power must comply with safety standard. The voltage and frequency should be consistent with the name plate of the semi product.
- 3.We won't take any responsibilities for malfunction; electric shock and leakage of electricity caused by disconnect any connecting wires during Installation or in use.


MAINTENANCE MANUAL

- 1.After use, wipe dry the surface.
- 2.Daily clean should be use the soft fabric and general liquid detergent except for Acetone or Ammonia. To clean the plaster stain could be erased by soft fabric with gasoline.
- 3.Not to hit or scratch to the surface of product. Lightly damage on the surface (white body), rubbed by 1500# abrasive paper with water, and then polished repeatedly by soft fabric with toothpaste.
- 4.Chrome plating or Gold plating products should not clean constantly. (can't meet the organic solvent)
- 5.After using, drain off the water in steam generator in order to extend the life time of the product.
- 6.If the water goes out slowly, just take out the cover of drainer, clean the trash such as hair inside, and then re-cover it.
- 7.Regular check for the electric wire, on-off and plug whether damaged by mouse, ant or worm to avoid any unnecessary loss.
- 8.Regular check for the flow pipe and drainage pipe if it's working and in good condition.
- 9.Keep the environment ventilated and dry. No aggressive gas. Cut off the water and electric power while the product is not in use often.
- 10.Replaced electric wire should be from manufacturer or exclusive shop, and to be installed by qualified electrician or specialist.
- 11.Maintenance of wooden floor:
 - (1)Not to scratch the wooden floor, clean with liquid detergent and soft fabric.
 - (2)To clean the trash and hairs inside the drainer by move out the movable board and the cover of drainer.


Parts list

1  x1	2  x1	3  M6×30 x12	4  x1
5  ST4×14 x5	6  x1	7  x1	8  x6
9  x1	10  x1	11  x1	12  ST4×14 x3
13  x2	14  x2	15  x1	16  x2
17  x1	18  x1	19  M4×14 x10	20  x1
21  x1	22  x1	23  x1	24

Bathtub installation




Wall panel installation




6

Installation for wall panel and bathtub




7

Shower panel installation




8

Fixed glass installation




9

Head cover installation




10

Active glass installation




11




Active glass installation



Aluminum adjustment installation





Shower installation



14

Fixation for roof to wall



15

Fixation for roof to wall



24h

